

## WebCam Installation Guide for: Logitech QuickCam Pro 5000

NOTE: **DO NOT** CONNECT THE CAMERA TO THE COMPUTER BEFORE INSTALLING THE SOFTWARE.

To install the software first, insert the Logitech camera software CD into your computer's CD-ROM drive. The Setup screen should appear. If it does not, please do the following:

1. Click "Start," and then "Run."
2. Type "D:\Setup.exe" and press the Enter key, where D: is the drive designation of your CD-ROM.
3. Follow the on-screen instructions.

After the computer reboots, the driver installation for the camera will start. Do not connect the camera until the setup prompts you to connect the camera cable to your computer.

While the driver installation progresses, remove the camera and camera base from the packaging and mount the camera on the camera base.

When prompted, plug the camera into the USB port. You should see the following diagram to let you know when to plug the camera in.



After the installation is complete, the camera should be ready to use.

**\*Note:** If you do not have the CD for the Logitech camera then you can find the drivers at the following link:

<http://www.logitech.com/index.cfm/downloads/software/US/EN,CRID=1794,contentid=6023>

Click on "Download" and save file to your Desktop.



After Download is complete, locate file on your desktop and double click to start installation. Follow Logitech instructions to install driver/software.

